



NOTE: ROUGH OPENINGS SHOULD BE FLASHED WITH AN APPROPRIATE MOISTURE BARRIER IN ACCORDANCE WITH INDUSTRY STANDARDS AND/OR BUILDING CODES. PERIMETER CAULK DOOR FRAME TO MOISTURE BARRIER AFTER INSTALLATION. USE SEALANT THAT IS RECOMMENDED BY MOISTURE BARRIER MANUFACTURER.

- CHECK ROUGH OPENING TO VERIFY THAT IT IS PLUMB, LEVEL AND APPROXIMATELY $\frac{1}{2}$ WIDER AND $\frac{1}{2}$ TALLER THAN THE NET FRAME SIZE.
- DRY FIT ASSEMBLY MAIN FRAME MEMBERS - AVOID DAMAGING FINISH.
- ADJOIN TRACKS AS NECESSARY TO FIT REQUIRED OPENING. CENTER FRAME IN OPENING AND TEMPORARILY SHIM JACKS. IF FLOOR IS NOT LEVEL, SHIM THRESHOLD AS REQUIRED.
- PUMP SEALANT INTO HOLES PRIOR TO INSERTING SCREWS TO ENSURE PENETRATION IS SEALED COMPLETELY.
- BUTTER ALL JOINTS WITH APPROPRIATE SEALANT TO ENSURE THE SEAL IS COMPLETE.

NOTE : THIS IS A TOP HUNG PRODUCT - PROVIDE ADEQUATE STRUCTURE AT HEAD.

